



STS UNIT CONSOLE + POWER CORD

Connectivity scheme




Installation scheme



POWER CORD CONNECTION

(PLEASE CONNECT STS TO POWER ONLY IN RALLY CAR, DURING RECCE STS USE INTERNAL BATTERY)



SPECIAL INFORMATION STICKER PLACE:



Attention!
Press **SOS** button to request **immediate assistance!**



If vehicle stops on a special stage, an alert will be raised automatically.
You have **only 30 sek.** to push **OK** button to indicate to all monitoring stations that you do not require assistance.

30SEC

RACE CONTROL CENTER

+372 73 55 100

